

Memor - General Info

On & Off

The on/off button is on the left side of the unit. A short click will switch the unit on and a longer click will switch it off.

If you switch the unit off whilst you're still in the StockMate program, when you switch back on again, you will still be in the StockMate program. i.e. it isn't a reboot.

Battery

The standard battery will typically last a day, depending on the amount of use and scanning.

A double-capacity battery is available.

When the battery is getting low, the red-light indicator at the the top right of the unit will flash.

Charging

The best way to re-charge the battery is with the mains adaptor. Charge time is relatively short, about 1 hour.

An alternative way is via the USB cable. To do this, the unit must be switched off.

When the battery is being charged, the red-light indicator at the top right of the unit will be lit up.

Keys

F1	Code search
F2	Description search
Esc	Go back/Cancel
Enter	Accept
Numbers	Numbers
Dot	Decimal Point / Code search
Joystick	Move up/down search list
Blue → Esc	Toggle back light on keyboard
Yellow → Esc	Toggle back light on screen
Alpha	Toggle keypad to/from letters
Scan	Scan a barcode
BkSp	Delete a character



Screen

The screen is touch sensitive and be operated either with the stylus or your finger.

The screen backlight will automatically switch off after 1 minute, if there is no activity. To bring it back on again, click on the screen.

The switch-off delay can be changed in Control Panel/Settings/Display.

Stylus

The stylus can be used much like a mouse

Single-click

Double-click

Click-and-drag

It only requires a brief and light tap.

Communications

The unit links to the laptop using a USB cable.

Windows Mobile needs to be downloaded and installed.

Windows Mobile will run automatically when the unit is connected. If it doesn't start, disconnect and then connect again.

Reboot

A reboot may be needed if the StockMate program freezes, or Windows freezes.

If required, for a 'warm boot' press and hold the **Esc** key and press the **On/Off** button.

If a 'warm boot' does not work, do a 'cold boot'. Press **Esc**, **Joystick** and **On/Off**, all at the same time.

Memory Backup

The stock data is held in a folder called "Liquor". Then, within this folder there are sub-folders for each outlet.

The Memor unit has some 'permanent' memory in a folder called 'Backup'. After every operation, a copy of the live files is sent to the backup folder.

Files in this folder will be retained, even when the battery runs down or is taken out.

If you have to do a 'cold boot' (see above), you will need to connect up to the laptop and do a 'Download Programs'. Then, when you run the program, it will report that there are no live outlets but there are some in the backup. It will then restore all data from the backup.